# DART SERVICE INSTRUCTION


TO AMEND INSTALLATION INSTRUCTIONS D350-567 REV. C

REF. CANADIAN STC: SH92-18 REF. FAA STC: SH989NE/SH990NE

To make the Dart D350-567-111 Vertical Reference Window Installation Kit at CHG 002 and D350-567-115 Interior Floor Window Kit at CHG 001 compatible with later AS350/355 Aircraft, it may be necessary to notch and reinforce the D3294-1 Bracket per Figure 1. This change is required to ensure that the D3294-1 Bracket will not interfere with the pilot's right hand aft seatbelt anchor structure (notch per View A of Figure 2) and/or the collective tube (notch per View B of Figure 2).

### **Procedure**


- 1) As required, notch D3294-1 Bracket per View A and/or View B of Figure 2. Views A and B of Figure 2 indicate the maximum size of the notch. If machining slot per View A, maintain a minimum edge distance of 0.125" from the edge of the holes.
- 2) Touch up affected areas on D3294-1 Bracket with chemical film (Alodine 1200/1201) per MIL-C-5541 before painting. Apply one coat of MIL-P-85582/MIL-P-23377 primer and 2-3 coats of MIL-C-83285 polyurethane paint to match original finish.
- 3) Prepare doubler per Figure 3. Figure 3 represents the minimum size of the doubler.
- 4) Prepare the doubler for paint with chemical film (Alodine 1200/1201) per MIL-C-5541. Apply one coat of MIL-P-85582/MIL-P-23377 primer and 2-3 coats of MIL-C-83285 polyurethane paint to match finish and color on D3294-1 Bracket.
- 5) Install Doubler on D3294-1 Bracket using MS20470AD4 Rivets as shown in Figure 1.
- 6) Install the modified D3294-1 Bracket in accordance with Installation Instructions D350-567.




# FIGURE 1: INSTALLATION OF DOUBLER

CANADA DEPARTMENT OF TRANSPORT AIRCRAFT CERTIFICATION BRANCH DAO # 01-0-01
BY: D. SHEPHERD (DE # 02)
DATE: 08.04.14  CERT. NO.: SH92-18  ISSUE NO.: 5

В		OTCH PI ER. REF	МВ	08.04.14		
Α	NEW ISSUE					07.10.05
REV.	<b>1</b> c			ESCRIPTION	BY	DATE
DESIGN			4	DART AEROSP	ACE	LTD
DRAWN 5			HAWKESBURY, ONTAR			
CHECKE	D	PH	Í	DRAWING NO.		REV. B
MFG. APPR.		U/A		DSI 9392	5	SHEET 1 OF 3
APPROVED		1 k	M	TITLE		SCALE
DE APP	₹.	di	-	BRACKET MODIFICATION		NTS
DATE 08.04.14				COPYRIGHT © 2007 BY DART AEROSPACE LTD  THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.		



## FIGURE 2: DETAIL OF D3294-1 NOTCHES



# CANADA DEPARTMENT OF TRANSPORT AIRCRAFT CERTIFICATION BRANCH DAO # 01-0-01

D. SHEPHERD (DE # 02)

DATE: 08.04,14


CERT. NO.: SH92-18

ISSUE NO.: 5

### **FIGURE 2 NOTES**

- 1) UNITS: INCHES UNLESS OTHERWISE NOTED
- 2) BREAK SHARP EDGES: 0.005 TO 0.010 MAX


	1		
DESIGN	143	DART AEROSPAC	E LTD
DRAWN	4	HAWKESBURY, ONTARIO, CANADA	
CHECKED	PH	DRAWING NO.	REV. B
MFG. APPR.	WAO	DSI 9392	SHEET 2 OF 3
APPROVED	1 sal	TITLE	SCALE
DE APPR.	di-	BRACKET MODIFICATION	NTS
DATE 08.0	4.14	COPYRIGHT © 2007 BY DART AEROSPACE LTD  THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS  NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT  WRITTEN PERMISSION FROM DART AEROSPACE LTD.	



### **DOUBLER FLAT PATTERN**

### **DOUBLER NOTES:**

- 1) MATERIAL: ALUMINUM 2024-T3 (QQ-A-250/4) SHEET 0.080 THICK
- 2) UNITS: INCHES UNLESS OTHERWISE NOTED
- 3) BREAK SHARP EDGES: 0.005 TO 0.010 MAX



### **FIGURE 3: DOUBLER DETAIL**



	- 1			
DESIGN	1 lbs	DART AEROSPAC	CE LTD	
DRAWN	5	HAWKESBURY, ONTARIO, CANADA		
CHECKED	PH	DRAWING NO.	REV. B	
MFG. APPR.	WA	DSI 9392	SHEET3 OF 3	
APPROVED	IM	TITLE	SCALE	
DE APPR.	di	BRACKET MODIFICATION	NTS	
DATE 08.0	4.14	COPYRIGHT © 2007 BY DART AEROSPACE LTD  THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS  NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT  WRITTEN PERMISSION FROM DART AFROSPACE LTD.		